




Jolie

QUICK START GUIDE

Preuzmite
priručnik
Download
the PDF manual



PRVA UPOTREBA / FIRST USE




Isperite rezervoar za vodu, napunite ga do oznake MAX i uključite utikač u utičnicu. Pritisnite dugme da uključite aparat i sačekajte da dugme zasvetli stalnim belim svetlom.

Rinse the water tank, fill it to the indicated MAX level. Plug the machine into the power outlet. Press the button to switch the machine on and wait until the button shows a steady white light.



Pritisnite dugme da pokrenete ispuštanje vode, ispraznite ceo rezervoar i ponovo pritisnite dugme da završite postupak.


Press the button to start delivering at least one tankful of water and press it again to stop delivering.



Nemojte koristiti prvu ispuštenu vodu. Za isključivanje držite dugme pritisnuto najmanje 3 sekunde ili sačekajte automatsko isključivanje nakon 2 minuta.


Do not use the first delivered water. Keep the button pressed for at least 3 seconds to switch off the machine or wait 2 minutes for the automatic off-mode.

SVAKODNEVNA UPOTREBA / DAILY USE




Proverite da li je rezervoar pun. Podignite ručicu, ubacite kapsulu i spustite ručicu. Pritisnite dugme i sačekajte da se pripremi željena količina kafe.

Make sure that the tank is filled up. Raise the capsule loading lever, insert the capsule and lower the lever. Press the button once, then wait for the desired amount to be supplied.



Kada se pripremi željena količina, ponovo pritisnite dugme da zaustavite istakanje. Za isključivanje držite dugme pritisnuto najmanje 3 sekunde.

Press the button again to stop the supply. Keep the button pressed down for at least 3 seconds to switch off.



Posuda za iskorišćene kapsule ima providni prozor kroz koji se vidi koliko je puna. Ako LED lampica treperi brže, ispraznite posudu i resetujte uređaj pritiskom na dugme ON/OFF.

The used pod collecting drawer has a transparent window that allows you to see how full the drawer is. If the LED flashes faster, empty the capsule drawer and reset it by pressing the ON/OFF button.




QUICK START GUIDE

Jolie

POSTUPAK DEKALCIFIKACIJE / DESCALING PROCEDURE



Dekalcifikaciju je potrebno obaviti na svaka 2-3 meseca korišćenja i/ili kada je protok vode oslabljen, ispuštanje otežano ili kafa nije dovoljno topla. Descaling will be required every 2-3 months of machine use and/or when delivery becomes difficult owing to reduced water flow and/or when the coffee is not hot enough.



Napunite rezervoar sredstvom LAVAZZA za dekalifikaciju (250 ml) i vodom (250 ml). Mogu se koristiti i dekalifikatori drugih pouzdanih proizvođača, prema njihovom uputstvu. Ne ubacujte kapsulu. Fill the tank with LAVAZZA descaler (250 ml) and water (250 ml). Descalers from other reputable manufacturers may also be used according to their instructions. Do not insert a capsule.




Ispustite jednu šolju rastvora za dekalifikaciju (oko 60 ml), zatim sačekajte 15-20 sekundi. Ispraznite posudu za prikupljanje rastvora. Ponavljajte dok se rezervoar potpuno ne isprazni.

Deliver one cupful of descaling solution (about 60 ml), then wait approximately 15-20 seconds. Empty the container used to collect the solution. Repeat until the water tank is completely empty.



Skinite rezervoar za vodu, isperite ga i temeljno operite. Remove the tank and rinse it with fresh drinking water.



Napunite rezervoar svežom negaziranom vodom za piće do oznake MAX. Vratite rezervoar na aparat. Fill the tank to the MAX level with fresh drinking water and place it back onto the machine.



Ispustite svu vodu iz rezervoara da biste završili postupak. Empty the water tank completely to finish the process.

❗ Pažljivo pročitajte detaljno uputstvo za dekalifikaciju u online korisničkom priručniku.

Carefully read the detailed descaling instructions provided in the online user manual.

⚠ Ukoliko se dekalifikacija ne obavlja redovno, servis u okviru garancije neće biti odobren.

Failure to regularly descale the coffee machine, assistance under warranty shall not be provided.

⚠ Ne koristite sirće kao sredstvo za dekalifikaciju.

Never use vinegar as a descaling agent.

10084053 Rev. B